

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address 14 Miller Lane Address where you reside Jericho VT 05465

TO BE COMPLETED BY RESIDENT

Water was last used: Time 10:40 PM Date 6-10-03

Sample was collected: Time 6:33 AM Date 6-11-03

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature (Sign)

(Please print name)

Date 6-10-03

(Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address Address where you reside

TO BE COMPLETED BY RESIDENT

Water was last used: Time 11 pm Date 6/9/03
 Sample was collected: Time 8:30 am Date 6/10/03

I have read the above directions and have taken a tap sample in accordance with these directions.

Pat Richmond
 Signature (Sign)

Pat Richmond
 (Please print name)

Date 6/10/03
 (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address 390 VT RT 15 Jencho VT 05465 Address where you reside 390 VT RT 15 Jencho VT 05465

TO BE COMPLETED BY RESIDENT

Water was last used: Time 11:45 PM Date 6-9-03
 Sample was collected: Time 6:04 AM Date 6-10-03

I have read the above directions and have taken a tap sample in accordance with these directions.

Peter H. Mitchell Date 6-10-03
 Signature (Sign) (Please print name) (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address Address where you reside

TO BE COMPLETED BY RESIDENT

Water was last used:

Time 11:00 PM

Date 6/9/03

Sample was collected:

Time 5:15 AM

Date 6/10/03

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature (Sign) Steve Guay (Please print name)

Date 6/10/03
(Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address 9 Meadow Lane Underhill, Vt. 05489 Address where you reside 9 Meadow Lane Underhill, Vt. 05489

TO BE COMPLETED BY RESIDENT

Water was last used: Time 6:45 P.M. Date 6-10-03
Sample was collected: Time 2:00 Am Date 6-11-03

I have read the above directions and have taken a tap sample in accordance with these directions.

B. Agrasta Barbara Agrasta Date 6-10-03
Signature (Sign) (Please print name) (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address Address where you reside
2 Dumas Road
UNDERhill, VERMONT 05489-9495 SAME

TO BE COMPLETED BY RESIDENT

Water was last used: Time 11:45 PM Date 6/10/03

Sample was collected: Time 5:45 AM Date 6/11/03

I have read the above directions and have taken a tap sample in accordance with these directions.

Douglas L Keith DOUGLAS L KEITH Date 6/11/03
Signature (Sign) (Please print name) (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address 385 VT Rt 15 Address where you reside SADT E
JERICHO VT

TO BE COMPLETED BY RESIDENT

Water was last used:

Time 12:45 A.M. Date 11 June 03

Sample was collected:

Time 6:15 A.M. Date 11 June 03

I have read the above directions and have taken a tap sample in accordance with these directions.

John R Fowler John R Fowler Date 11 June 03
 (Signature) (Please print name) (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address _____ Address where you reside _____

TO BE COMPLETED BY RESIDENT

Water was last used: Time 11:00 PM Date 6-10-03

Sample was collected: Time 7:35 Date 6-11-03

I have read the above directions and have taken a tap sample in accordance with these directions.

Sharon Brigham SHARON BRIGHAM Date 6-11-03
Signature (Sign) (Please print name) (Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address 19 Parker Hill Rd Address where you reside Underhill, VT 05489

TO BE COMPLETED BY RESIDENT

Water was last used:

Time 10:30 pm Date 6-10-03

Sample was collected:

Time 5:40 am Date 6-11-03

I have read the above directions and have taken a tap sample in accordance with these directions.

Bev Frank
Signature (Sign)

Bev Frank
(Please print name)

Date 6-11-03
(Date signed)

Suggested Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

1. Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick-up by water department staff.
2. A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
3. A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THE LABEL AS PROVIDED.
6. Place the sample kit outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Call Marc Maheux at 899-3810 if you have any questions regarding these instructions. Your mailing address Address where you reside

TO BE COMPLETED BY RESIDENT

Water was last used: Time 6:00 PM Date 6-10-03

Sample was collected: Time 7:45 AM Date 6-11-03

I have read the above directions and have taken a tap sample in accordance with these directions.

Marc Maheux

Signature (Sign)

Marc Maheux

(Please print name)

Date 6/11/03

(Date signed)